

PLANT PROTECTING INSTRUMENT

Soil Sampler Device

1m

● Characteristics

- ▲ Stainless steel, no pollution to soil and reduce the labor intensity
- ▲ Spiral bottom, and it can be detachable to use as extension rod for Soil Moisture meter.
- ▲ Pointed bottom, labor- saving.
- ▲ One scale for each 10m, the diameter of bottom is 6cm.
- ▲ Total length: 1m



Soil Sampler Kits

Model: TPLQ-2



Accessories: 1 brush, 1 spanner,
1 tape 3meters, 1 scraper, 1 handle,
1 head, and 4 tubes

Length: 1m, 1.5m, 2m

Wind Suction Pest-killer for Tea Garden AC & DC

Model: TPCZ5

● Characteristics

- ▲ Both AC and solar power supply available.
- ▲ LCD display, Stainless steel rack.
- ▲ Light control: auto-shut up and down according to day and night
- ▲ Rain control: Auto-protection in rainy days, when humidity above 95% RH, the frequent vibration lamp will be in the state of auto-protection, or it will work normally
- ▲ Time control: working time can be setting according the pests' life routine.
- ▲ Optics, electricity, CNC technology in automatic control system.
- ▲ Control area per lamp: 10-20Mu
- ▲ Energy saving: when working on light or time control method, the fans is working in the low speed condition.

● Technical parameters

Power: AC220V / 50Hz, DC12V, ≤30W. Solar cell: ≤40W

Insulation resistance: ≥2.5MΩ

Trap tube: wavelength 385+395+420nm, ≤12W. Life span: ≥5000hours

